

**FORESTUFF**

# Installation Instructions

- Ford Focus ST MK3 2.0 vFL BJ 2012-2015
- Ford Focus ST MK3 2.0 FL BJ 2015-2019
- Ford Focus RS 2.3 AWD
- Ford Focus ST MK3 Diesel
- Ford Focus ST MK4



1. Remove original downpipe holder
2. Remove original bearings by cutting them out [1]
3. Insert Foresight bearing with the narrower side on the outside [2]  
(We recommend spraying the bearing recesses with WD-40 or similar)
4. Installing the downpipe holder

*If you have problems with the installation or need further information, you can watch our installation tutorial on YouTube.*

*Just use the following QR Code:*

*( <https://youtu.be/Dj3DgFHhUJI> )*



We will be happy to answer any questions about the product or provide assistance with installation if you don't know what to do.

Write us an e-mail to [info@foresight-shop.de](mailto:info@foresight-shop.de)  
and we will help you as soon as possible.