


FORESHIFT

Installation Instructions

- Toyota Yaris GR


(We recommend that the installation be carried out by qualified specialists!)

1. Unlock 2x clamps [1] of the air filter box by pulling lightly
2. Loosen hose clamp (SW10) [2] on air filter box
3. Unplug mass air flow sensor [3]
4. Remove mass air flow sensor [4] from air filter box cover
5. Remove air filter box cover




Picture 1

6. Loosen 2x clips from the intake [5] by levering them out slightly




Picture 2

7. Unscrew the screw (SW8) on valve [6] (Picture 1) from the air filter box and unclip the vacuum hose [7] from the brackets and from the valve




Picture 3



Picture 4


8. Unclip the air filter box by pulling it upwards

9. Unclip the last holder [8] from the air filter box and remove it




Picture 5

10. Remove safety clip [9] from shift linkage (Caution: risk of loss!)




Picture 6

11. Assemble short shifter and shifting linkage correctly




Picture 7

12. Carefully slide short shifter onto shift cable mount




Picture 8

13. Screw the grub screw [10] into the short shifter and tighten it




Picture 9



Picture 10

14. Insert Allen screw [11] and tighten it with 11 Nm



Picture 11

15. Check that the short shifter is fixed firmly in place

16. Check again that the gearshift is functioning correctly

17. Installation in reverse order

If you have problems with the installation or need further information, you can watch our installation tutorial on YouTube.

Just use the following QR Code:

(<https://youtu.be/rFFRQEy4yas>)



We will be happy to answer any questions about the product or provide assistance with installation if you don't know what to do.

Write us an e-mail to info@foresight-shop.de
and we will help you as soon as possible.